

Maintenance guide

Cleaning

To clean your board, it is best to use warm, soapy water.

-  Never leave the board submerged in water and don't put it in the dishwasher.
-  Let it air dry before storing it.

Maintenance

To restore your board, once a month or whenever the board appears dry, depending on its use, you can apply a "food safe" maintenance product.

We recommend our product made from grape seed oil and natural beeswax.

01 Before applying the product, make sure to clean the board thoroughly and allow it to dry completely.

02 Apply the product generously over the entire surface of the board, ensuring every corner is well covered.

03 Allow the product to penetrate for 20 to 30 minutes to ensure optimal absorption.

04 Remove the excess with a dry cloth.

05 Rub sufficiently to achieve a smooth surface.